

Heat Seal Machine Instructions

1. Turn on heat press and **wait** to allow for it to get up to temperature (above 200 degrees C) before beginning heat sealing.
2. Run the heat press through one full cycle **WITHOUT** any garments to warm up the rubber pad before use. This should be done before each run of heat sealing where the heat press has been left idle for over 5 minutes.
3. Place the garment flush over the rubber pad and heat seal the label onto a fresh area of fabric.



Do **not** heat press labels onto 'garment care' or clothing brand tags.



Do **not** heat press new label to an area where an old label has come off.



Do **not** heat press over any clothing seams.

4. When heat pressing, wait for the buzzer to sound before lifting the press.
 - Do **not** lift the press before the buzzer sounds.
 - Do **not** leave the press buzzing for more than 2 seconds.
5. Turn off heat press when done.